,0015

DAVENPORT MACHINE CONDITION CHECK-LIST DATE 6 14 23 MACHINE # D 27 INITIALS

CHECK AND RECORD MACHINE CONDITION

		Α	В	C
1.	Clean and inspect mist collector	Х		
	A. Remove filters and clean	X		
	B. Condition of belt	×		
	C. Condition of motor	×		
	D. Condition of bearings	×		
	E. Condition of ionizer wires	X		
1.	Stud and Bushing in "C" position Swing Arm	×		
2.	Stud and Bushing in "E" position Swing Arm	X		
3.	Check gap between Revolving Head and Cap	x		
4.	Check for excessive end play of revolving head.	×		
5.	Check head locking and locating arm for the following conditions: Pin, bushings, head movement when locking, proper clearance between locating block and the lever, roll and pin.	×		
6.	Work Spindle Condition: Side play Spindle #1 Record 0035-004 Spindle #2 Record 003-0035 Spindle #3 Record 002-0035 Spindle #4 Record 003-0035 Spindle #5 Record 003-0036			
7.	"A" position cross slide	X	1	
8.	"B" position cross slide	V		- 9
9.	Check feed mechanism	V		
10.	Check chuck opening mechanism	1x	1	

FORM 020-80-20 Rev. 5 06/11/2021

11.	Check chuck closing mechanism	
12.	Check tension of main drive and lube pump belts	200
13.	Inspect chuck and feed cam	8
14.	Lube System and Gauges:	X
	A. Remove and clean lube tank.	X
	B. Clean metal screens and replace pump filter	X
	C. Check pressure gauges	4
	D. Check pump operation and correct pressure	X
	E. Inspect lines and manifolds for damage and correct oil output as specified	*
	F. Drain and replace oil in worm housings	×
	G. Verify oil output at threading clutch manifold	X
15.	Inspect hand clutch	X

A = Acceptable

B = Repaired

C = Schedule for Repair

ZULLG-74 oil filter	
(susppro Pump)	
(- round or 10 of F	
Coller for proper fit	200

FORM 020-80-20 Rev. 5 06/11/2021